

SOFT START CABINET



Description	Functions
<ul style="list-style-type: none">• Overload protection• Built-in HP /LP safety• General switch + ventilation• On/Off function• Remote control input• Fault viewing• Available for several powers:<ul style="list-style-type: none">• 32A max• 47A max• 62A max• 75A max• 88A max• 110A max• 140A max• 170A max• 210A max	<ul style="list-style-type: none">• Automatic mode start on external contact (pressure switch, level relay, etc.) or clock/timer• Manual start-up using the push button on the front• Several options available:<ul style="list-style-type: none">• No flow stop• Unpriming• 24H timer• 24H clock• Time meter• Voltmeter• 40A differential switch• 63A differential switch• Heating element safety• Threshold ammeter